

HF000160 – Marble Console Table Instruction Manual

Safety Instructions – please read and retain for future reference.

After unpacking, check the product for signs of transit damage - do not use if damage is found.

Keep away from fire or flammable materials.

The maximum load weight for this table/shelf is 8 kilograms.

Check that the product is stable before using it. Do not lift or move the product when it is loaded.

Parts of the assembly will be easier with 2 people.












Only use on an even/level surface.

During assembly children should be kept away from the product due to possible risk of injury. Do not allow children to play with or on the table.

To ensure an easier assembly, we strongly advise that all fittings are only finger tightened during initial assembly. Only upon completion of the assembly should all fixing points be fully tightened.

This product is to be used solely for domestic purposes.

Description of Parts

			
AX2		CX1	
Leg Frame		Bottom Fixing Pole	
			
BX2		DX1	
Top Fixing Pole		Tabletop	
			
EX6	FX6	GX1	
Fixing bolt	Tabletop Screw	Allen key	
			
HX1	IX1	JX1	KX1
Table fixing Screw	Wall Plug	Wall fixing Screw	Wall fixing

Care and Maintenance


Rinse the table and use a sponge or soft bristle brush to scrub with a mild cleaning solution.

Lastly, rinse the furniture with fresh water; never soak or immerse in water.

From time to time, check that there are no loose screws or bolts on this unit.

Assembling the console table


STEP 1: Align the openings on the top of the leg frames (A) with the opening on the top fixing poles (B). Fix into place using 4 of the fixing bolts (E) & Allen key (G) provided, ensuring that the screw loopholes on the poles are facing inwards.



STEP 2: Insert the bottom fixing pole (C) into the leg frame as per image above and secure it into place with two fixing bolts and the allen key.

STEP 3: Once the frame of the large table has been constructed, rest the tabletop (1) on top of the frame, ensuring that the screw holes within the wood are facing downwards.

STEP 4: Fix the tabletop onto the frame using a screwdriver and the 6 tabletop screws (F) provided.




Fixing the table to the Wall

WARNING: make sure that there are no electrical, plumbing or gas suppliers situated beneath the surface of the wall. Testers are available from all good DIY stores.

STEP 1: Using a pencil, mark the screw hole location on the desired surface. Make sure that the hole is marked accurately and, in the positions, required for the table.

STEP 2: Using a suitable drill bit, drill a pilot hole at each marked location. Consult a qualified professional if required.



STEP 3: Insert the wall plug (I) into the pilot hole so that the wall plug sits flush with the wall surface.

STEP 4: Fix the wall mount fixing (K) to the underside of the top table (D) using the table fixing screw (H) provided.

STEP 5: Align the opening on the wall mount fixing with the openings on the wall plug. Fix the table to the wall with the wall fixing screw (J) provided and a Pozi screwdriver.

Disposal

This product should not be discarded within household waste. Take to your local recycling station for disposal.

Model Number: HF000160

Dimensions: 76x56x26cm (approx.*)

Manufactured by: Online Home Shop LTD, Priestley Road, Manchester, M28 2LX, UK

For Online Support: support@onlinehomeshop.com

Made in China